

ASSEMBLY INSTRUCTIONS

MODEL: 82333

Konfurb

Before assembly, please remove all parts from the carton, verifying that you have the correct quantities, and read all the instructions.

INSTRUCTIONS:

1

3

IN THE CARTON:

| ① STEEL LEG | ② CONNECTING TUBE | ③ SEAT UNIT | ④ SCREW M6*16 | ⑤ ALLEN KEY |
|-------------|-------------------|-------------|------------------|-------------|
| | | | | |
| 2 PCS | 2 PCS | 1 PC | 4 PCS | 1 PC |

⚠ ATTENTION ⚠

Do not tighten any screws or bolts until the unit is completely assembled.

Ensure all bolts and screws are tightened before using, check bolts and screws every 6 months.

If any parts are missing, broken, damaged or worn, stop use of product until repairs have been made using factory authorized parts.

Failure to follow these warnings may result in injury.