




Door Hinge Adjustment

Follow this diagram to adjust your cabinet and hutch doors.

Note: Over time, your doors may shift or sag. This does not mean that the hinges have worn out - they simply need adjusting.




1 Sideways / Tilt adjustment

Turn the screw:

↻ **Clockwise** to move the door further away from the side of the cabinet.

↻ **Anti-clockwise** to move the door closer to the side of the cabinet.




2 4 Height Adjustment

While supporting the weight of the door, turn the screws:

↻ **Clockwise** to move the door up.

↻ **Anti-clockwise** to move the door down.



3 Forward and back adjustment

If the gap between the back of the door and the cabinet is too small, the door may not close fully. Turn the screw:

↻ **Clockwise** to decrease the gap between the door and the cabinet.

↻ **Anti-clockwise** to increase the gap between the door and the cabinet.

