
















Please follow these instructions for easy assembly.

|   |   |   |  |   |   |   |   |
|---|---|---|--|---|---|---|---|
| <b>A</b><br><br>Cam Lock<br>11 Pcs | <b>B</b><br><br>Klix Cam<br>11 Pcs | <b>C</b><br><br>Housing<br>Cap (Long)<br>4 Pcs | <b>D</b><br><br>Housing<br>Cap (Short)<br>7 Pcs | <b>E</b><br><br>Adjustable<br>Glide<br>4 Pcs | <b>F</b><br><br>6 Hole<br>L-Bracket<br>5 Pcs | <b>G</b><br><br>Screw<br>#6 x 5/8"<br>30 Pcs | <b>H</b><br><br>M4 x 65<br>Allen-Key<br>1 Pc |
|---|---|---|--|---|---|---|---|

|  |   |  |
|--|---|--|
| <b>1</b><br><br>Top Panel | <b>2</b><br><br>Side Panel x 2 | <b>3</b><br><br>Back Panel |
|--|---|--|

### KLIX CAM INSTRUCTIONS


|  |  |  |
|--|--|--|
| <b>1</b><br><br>Line up Cam Lock,<br>turn clockwise. | <b>2</b><br><br>Insert the cam with the arrow<br>pointing towards the hole in the<br>edge. | <b>3</b><br><br>Insert the Cam Lock into Klix<br>Cam. Turn Klix Cam to lock. |
|--|--|--|



### IMPORTANT !


- Place all wooden parts on a clean and smooth surface such as a rug or carpet to avoid the parts from being scratched.
- Check that you have all parts and hardware.
- Remove all wrapping materials, including staples & packing straps before you start to assemble.
- Do not tighten any screws or bolts until the unit is completely assembled.
- Keep all hardware parts out of reach of children.

1



Attach Back Panel (3) to Left(2) and Right Side Panel(2) by using Cam Lock(A) and Klix Cam(B).



3



Screw Adjustable Glide(E) into bottom of Side Panel.


2

Attach L-Bracket(F) to Top Panel(1), Back Panel(3) and Side Panel(2) as shown. Tighten Screws(G) securely.



Attach Back Panel (3) and Side Panel (2) by using Cam Lock(A) and Klix Cam(B).

4



Attach Housing Cap(C) or (D) to all Klix Cam(2) by pushing neck thought center of cam.